

HEY DUGGEE

Let your child learn while having fun with Duggee and the Squirrels.

With five activities to encourage learning about colours, numbers, shapes, letters, characters & badges.



HOW TO PLAY

Press  to turn the tablet on.

Press any image to discover its name and sound.

Press the button once to identify the badges, press again for more information

Press these buttons to identify colours

Press the button once to learn about the characters, press again for more information

Learn about numbers and shapes

Press to hear questions

Press the button once to identify letters and phonics, press again to hear more

On/Off Button

Press here at any time during a game to hear funny sounds

Sound volume - and +

AUTOMATIC SHUT OFF: In order to save the batteries, the unit switches off after about a minute of inactivity. To re-activate the unit press the ON/OFF button.

How to change batteries

1. This product requires 3 x AAA (LR03) 1.5V batteries.
2. Use a suitable screwdriver to remove the battery cover located on the rear of the product.
3. Insert 3 x AAA batteries, ensuring the + and - terminals match the markings on the inside of the compartment.
4. Fit the battery compartment cover and tighten the screw to secure (but do not over-tighten).

Important battery information

Batteries must be inserted or removed by an adult.

Do not mix battery types (for example, alkaline and zinc carbon), or old and new batteries.

Do not attempt to recharge non-rechargeable batteries, as they may leak or explode.

Batteries must be inserted with the correct polarity.

Do not short circuit the supply terminals.

Remove exhausted batteries from the toy.

Remove rechargeable batteries from the toy before charging.

Rechargeable batteries must be charged by an adult.


Use only the recommended battery type or their equivalent.

Do not dispose of batteries in fire, as they may leak or explode.

Remove batteries from the toy if it is not being used for an extended period of time.



The purpose of the crossed-out wheellie bin symbol is to remind us that most electrical product and batteries contain trace elements which could be harmful to our environment and therefore our health. We must all be careful to dispose of them responsibly in a specifically designated way – either using a collection scheme or into the correctly labelled civic amenity (NOT into general waste) – this will help your local authority to arrange to recycle or dispose of them in the appropriate manner.



Trouble Shooting

If the tablet does not turn on...

Check that the batteries are installed correctly, or install new batteries.

If the volume is too low...

Install new batteries

The sounds are very high or low rate of speed...

Install new batteries

If there is a continuous buzzing sound...

Install new batteries

If the light of the toy becomes dim...

Install new batteries

Important information

Care Instructions

- **Keep the unit clear by wiping it with a slightly damp cloth**
- **Keep the unit out of direct sunlight and away from any direct heat source**
- **Do not expose the unit to moisture or water**

This product complies with the essential requirements of the European Toy Safety Directive.

As seen on



HEY DUGGEE (WORD MARK AND CHARACTER LOGOS) ARE TRADE MARKS OF STUDIO AKA LIMITED AND ARE USED UNDER LICENCE. HEY DUGGEE LOGO © STUDIO AKA LIMITED (2014). LICENSED BY BBC STUDIOS. BBC IS A TRADE MARK OF THE BRITISH BROADCASTING CORPORATION AND IS USED UNDER LICENCE. BBC LOGO © BBC 1996.

studio aka



For more fun learning toys go to
www.trendsuk.co.uk

Trends UK Ltd., Greatworth Hall, Banbury, OX17 2DH. UK

Email: trends@jgdirect.net


Trends Toys Ireland, 8-9 Marino Mart, Dublin 3, D03 P590



Remove all packaging materials before giving this toy to a child. Details and colour of parts may vary. Subject to availability.

Conforms to safety requirements.
Requires batteries: 3 x AAA.

Made in China.

 **Customer Services:**
+44 (0)1702 208175

Item Number: **HD21**